


Date Code Label  
Here



## In-Line Scooter Owner's Manual



This manual contains important safety, assembly, operation and maintenance information.

Please read and fully understand this manual before operation.

Save this manual for future reference.

See back page for Customer Service Information  
Consulte el reverso para Servicio de Información al Cliente  
Voir pages verso pour des renseignements le service à la clientèle

[ In the US ]

**PLEASE - BEFORE RETURNING TO STORE,  
CONTACT HUFFY CUSTOMER SERVICE. WE  
ARE GLAD TO ASSIST YOU WITH ANY PARTS  
OR ASSEMBLY PROBLEMS YOU MIGHT  
HAVE!**

For Fast Customer Service, go to:

<http://www.huffybikes.com/contact>

To Order Parts (US only), go to:

<http://www.huffybikes.com/parts>

OR TEL: 1 800 872 2453 (US only)

For email, go to <http://www.huffybikes.com/contact>

[ MÉXICO ]

**ANTES DE DEVOLVER EL  
PRODUCTO A LA TIENDA,  
COMUNÍQUESE CON SERVICIO  
AL CLIENTE DE HUFFY. NOS  
COMPLACE AYUDARLO CON  
CUALQUIER PARTE O PROBLEMA  
DE ENSAMBLADO QUE PUDIERA  
TENER.**

Para obtener Servicio al cliente rápido, visite:

<http://www.huffybikes.com/>

● LLAME AL TEL: 01800 1483 391

(Mexico only)

Para comunicarse por correo electrónico:

[servicio@huffymex.com](mailto:servicio@huffymex.com)



[ CANADA ]

**VEUILLEZ NOTER : AVANT DE  
RETOURNER AU MAGASIN,  
COMMUNIQUEZ AVEC LE SERVICE  
À LA CLIENTÈLE DE HUFFY. NOUS  
VOUS AIDERONS VOLONTIERS AVEC  
TOUT PROBLÈME CONCERNANT LES  
PIÈCES OU LE MONTAGE!**

Pour un Service à la clientèle rapide, allez sur le  
site :

<http://www.huffybikes.com/contact>

To Order Parts (CANADA only), go to:

<http://www.huffybikes.com/parts>

OU appelez le 1 800 872 2453

(CANADA only)

Pour communiquer par courriel

[huffycanada@huffy.com](mailto:huffycanada@huffy.com)

Check <http://www.huffybikes.com/home/globalcontact>  
for the current contact information

<http://www.huffybikes.com/home/globalcontact>  
para obtener la información de contacto actual

Vérifier <http://www.huffybikes.com/home/globalcontact>  
pour les informations de contact actuelles

H-Tri\_STOP-Global\_022217\_i0388





# Index

- Scooter Safety Information .....3-4
- Assembly ..... 5
- Operating the Scooter ..... 6
- Parts List..... 7
- Maintenance ..... 8
- Torque Table ..... 9
- Warranty ..... 10-11

## Helmet Warning Information

**⚠ WARNING:**  
**ALWAYS WEAR YOUR HELMET WHEN RIDING THIS PRODUCT!**

- Helmet should sit level on your head and low on your forehead. Exposed forehead can result in serious injury.
- Adjust the strap sliders below the ear on both sides.
- Buckle the chin strap. Adjust strap until it is snug.
- No more than two fingers should fit between the strap and your chin.
- A proper fitting helmet should be comfortable and not rock forward/backward or side to side.



**⚠ WARNING:**

- The toy shall be used with caution, since it requires great skill, so as to avoid falls or collisions causing injury to the user and third parties.
- This product must be assembled by an adult.

## Limited Warranty -continued

### How do you report a problem with this product or submit a warranty claim?

- Contact Customer Service in Australia or New Zealand. Warranty claims can be submitted to Huffy c/o Hunter Products Pty., Ltd., Level 2, 424 Warrigal Road, Moorabbin, Victoria 3189 Australia.

### What rights do you have?

- This Limited Warranty gives you specific legal rights. This Limited Warranty is in addition to other rights and remedies that a consumer may be entitled to under law with respect to this product.

The following text is incorporated into this Limited Warranty if this product was purchased in Australia (but it is not incorporated if such product was purchased in New Zealand):

- Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### What will Huffy do?

Huffy will replace, without charge to you, the component found to be defective by Huffy.

### How do you get service?

Contact Huffy Consumer Service.  
 See included list for Customer Contact information.

### How long does this warranty last?

- Deck - lifetime
- Fork - one year
- All other parts- six months
- Wheels - no warranty

## Limited Warranty

### General:

- Part or model specifications are subject to change without notice.
- This Limited Warranty is the only warranty for this product. There are no other expressed or implied warranties.
- This Limited Warranty extends only to the original consumer and is not transferable to anyone else.
- Warranty registration is not required.
- The only uses for this product are described in this manual.

### What does this Limited Warranty cover?

This Limited Warranty covers all parts of the product except those indicated below as not warranted.

### What must you do to keep the Limited Warranty in effect?

This Limited Warranty is effective only if:

- Product is completely and correctly assembled.
- Product is used under normal conditions for its intended purpose (see the following section for excluded activities).
- Product receives all necessary maintenance and adjustments.
- Product is used for general transportation and recreational use only.

### What is not covered by this Limited Warranty?

This Limited Warranty does not cover normal wear and tear, normal maintenance items, or any damage, failure, or loss that is caused by improper assembly, maintenance, adjustment, storage, or use of the Product.

### This Limited Warranty will be void if the unit is ever:

- Used in any competitive sport
- Used for stunt riding, jumping, aerobatics or similar activity
- Modified in any way
- Modified with the addition of a motor
- Ridden by more than one person at a time
- Rented, sold, or given away
- Used in a manner contrary to the instructions and warnings in this Owner's Manual

Huffy will not be liable for incidental or consequential loss or damage, due directly or indirectly from use of this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

## SCOOTER SAFETY INFORMATION

Scoters, like all wheeled vehicles, will provide safe, enjoyable transportation and recreation when used and maintained properly. Like bicycling, skateboarding, and in-line skating, riding a scooter can be dangerous even under the best of circumstances. We do not want you to get hurt. Please follow these safety rules.



This symbol is important. It is the WARNING symbol. The warning symbol precedes safety instructions. Make sure the child understands these instructions. Failure to follow these instructions may result in injury to the rider or to others, or damage to the product.



### WARNINGS TO AVOID SERIOUS INJURY:

- As required, adults must assist children in the initial adjustment procedures to unfold the scooter, adjust handlebar and steering to height, and finally to fold the scooter.
- This product should only be used by persons **5+** years.
- Not for children with a body mass of more than **110 lbs (50 Kg)**.
- Never ride with more than 1 person.
- Do not modify the product.
- **Protective Equipment must be worn.**
- Always wear safety equipment such as helmet, knee pads, elbow pads, wrist guards and gloves.
- While using the product, keep hands and fingers away from wheels and other moving parts to avoid danger of pinching or entrapment.
- Always wear a properly fitted AS/NZS approved helmet when riding the scooter and keep the chinstrap securely fastened.
- Always wear shoes when riding the scooter.
- Ride on smooth paved surfaces away from motor vehicles. Not for use on roads.
- Avoid sharp bumps, drainage grates, and sudden surface changes. Scooter may suddenly stop.
- Avoid streets and surfaces with water, sand, gravel, dirt, leaves, and other debris. Wet weather impairs traction, braking and visibility.
- Do not ride at night, dusk, or at times of limited visibility.
- Brake will get hot from continuous use. Do not touch after braking.
- Avoid excessive speed associated with downhill rides. It may be difficult to stop or maneuver quickly. Maximum recommended speed is 6 MPH (10 KPH).
- Obey all local traffic and scooter riding laws and regulations.
- Watch out for pedestrians.
- Do not wear headphones or anything else that would impair your ability to hear or see.
- Practice riding in large, flat areas.
- Avoid steeply sloped areas. Get off and walk.
- Know your limits. Be familiar with your scooter and your abilities. Use common sense.
- Handlebar hand grip or tube end-plugs should be replaced if damaged as bare tubes

## SCOOTER SAFETY INFORMATION - continued

have been known to cause injury. All products with capped handlebar ends should be checked regularly to ensure that adequate protection for the ends of the handlebars are in place.

- Ensure all locking devices are engaged before each ride.
- Check and secure all fasteners before every ride.
- Replace worn or broken parts immediately with original equipment.
- Before each ride, check that the steering system is correctly adjusted and that all connection components are firmly secured and not broken.


If you have any questions regarding the operation of this product, please refer to this owners manual or contact customer service.

## Torque Table

### Recommended Torque:

Use of a torque wrench is recommended. Recommended torque for each fastener is listed below. In addition to tightening to the recommended torque, please ensure the parts of the product are sufficiently tightened by performing the functional tests (in the component assembly sections of the owner's manual) on each component as it is tightened.

**NOTE:** Please check that all fasteners on the product are torqued according to the table:

Recommended Torque for clean, dry threads:		How to Measure:
<b>Fastener Size</b>	<b>Torque (ft-lb / N•m)</b>	Screw or bolt size is determined by the width at the THREADS as shown.
0.157 in (4 mm)	3.1 ft-lbs (4.2 N•m)	
0.196 in (5 mm)	5 ft-lbs (6.8 N•m)	
0.236 in (6 mm)	7 ft-lb (9.5 N•m)	
0.275 in (7 mm)	12 ft-lbs (16.3 N•m)	
0.314 in (8 mm)	17 ft-lbs (23 N•m)	
0.393 in (10 mm)	33 ft-lbs (44.7 N•m)	
0.472 in (12mm)	39 ft-lbs (52.3 N•m)	

## MAINTENANCE

The scooter should be checked periodically for any loose, broken, or worn parts. Tighten any parts that are loose, and replace any worn or broken parts immediately. Periodic cleaning will prolong the useful life of this scooter.

### SELF-LOCKING FASTENERS:

With repeated use, Self-Locking Fasteners may lose their ability to lock to the threads and may come loose. Frequently check Self-Locking Fasteners and replace when worn.

### INSPECTION OF THE BEARINGS:

Frequently check the wheel bearings of the product. Replace the wheels when the bearings do not pass the following tests:


Lift each end of the product off the ground and spin the raised wheel by hand:

- The wheel should spin freely and easily.
- There should be no side-to-side movement at the wheel edge when pushed to the side with light force.

### WEEKLY SERVICE:

Apply a few drops of general purpose oil to the sides of each wheel axle. Verify that the axle fasteners are tight.

## Assemble the Handlebar



**NOTE:** Point Fork FORWARD as shown.


1. Loosen Lock Screw (A) just far enough to insert Handlebar Post (B) and line up Mounting Holes (C) and (D).
2. Make sure Lock Screw goes through Clamp (D), Fork Tube (E) and into Handlebar Post Mounting Hole (C).
3. Tighten Lock Screw (A) securely.
4. Tighten Screw (F) securely so that Handlebar does not move.

**See Torque Chart for recommended torque.**


## OPERATING THE SCOOTER

The scooter is operated by placing one foot on the deck and pushing with the other foot. On some models the rear fender is hinged for use as a brake. On other models where the rear fender is not hinged, the foot used to propel the scooter is also used to stop the scooter. This is also the secondary brake method for models with hinged fender. Steering is accomplished by turning the handlebar and leaning into a turn.

**WARNING:** Always wear shoes when riding the scooter.



## Parts List



#	Description	#	Description
1	Handlebar	5	Fork
2	Handlebar Clamp	6	Wheel (x2)
3	Headset Bearings	7	Fender/Brake
4	Frame	8	Grips (x2)